





Bluetooth Phone App Control Parking Lock Operation Manual






A. For Apple IOS Version

1. Open google browser and click the camera
2. Click “open camera”



3. Scan the QR code on parking lock or we shared
4. Click “download”








Or you can search “Parking-Lock” application directly in your app store to download.







5. Click “open”
6. Click “allow” it to use bluetooth
7. Then connect, your phone can control the parking lock up and down







B. For Android Version

1. Open google browser and click the camera
2. Click “open camera”




3. Scan the QR code on parking lock or we shared
4. Choose first one “Android”







5. Click “download”




6. Click “don’t show again” and “allow” to allow your phone install the application.

7. Click “install”





8. Click “install” and you will find the the “car parking lock” application in your phone.



9. Open the application and phone bluetooth.

10. Click “allow all the time”

11. Let your phone connect parking lock by bluetooth, then your phone can make the parking lock up and down.

